

C23501 Push Button Waste

CRESTIAL
Wasser Musik

FEATURES

- brass body
- G1¼" outlet connection
- with overflow
- press down to close (fill basin) or press down again to open (drain water)
- Sundance chrome finish

