

C23511
Push button waste 1 1/4"

CRESTIAL
Wasser Musik

FEATURES

- G1 1/4" outlet connection
- universal fitting (for basins with / without overflow)
- fully brass
- press down to close (fill basin) or press down again to open (drain water)
- Sundance chrome finish

